

FIG. 1




FIG. 2

100

BIOS Setup Program: Boot Configuration

BIOS Boot Password: ***** 110

Default Boot Device: Western Digital Hard Drive ▾ 114

Boot Order: 102

- 1) Floppy Disk Drive 104
- 2) CD-ROM Drive 106
- 3) Western Digital Hard Drive 108

FIG. 3

100

BIOS Setup Program: Boot Configuration

BIOS Program Password: 112

BIOS Boot Password: 110

Default Boot Device: ▾ 114

Boot Order: 102

1) Floppy Disk Drive 104

2) CD-ROM Drive 106

3) Western Digital Hard Drive 108

FIG. 4

100

BIOS Setup Program: Boot Configuration

BIOS Program Password: ***** 110

Boot Order:

1) Floppy Disk

2) CD-ROM Drive

3) Western Digital Hard Drive

120

Boot Device

118

BIOS Boot Password

116

NONE (default device)

FIG. 5